

Kanaloversigt

		74kr/md			245kr/md			445kr/md		
Plads		Grund	Mellem	Fuld	Plads	Grund	Mellem	Fuld		
1	DR1	✓	✓	✓	52	Viasat Nature		✓		
2	TV2	✓	✓	✓	53	TLC		✓		
3	DR2	✓	✓	✓	54	Nick music		✓		
4	DK4	✓	✓	✓	55	MTV		✓		
5	TV2 Kosmopol	✓	✓	✓	56	CNN		✓		
6	Folketinget	✓	✓	✓	57	Sky News		✓		
7	DR Ramasjang	✓	✓	✓	58	BBC World		✓		
8	Hovedstaden	✓	✓	✓	60	BBC Nordic		✓		
9	Barnkanalen	✓	✓	✓	61	Discovery HD		✓		
10	SVT1	✓	✓	✓	62	Discovery Science		✓		
11	SVT2	✓	✓	✓	63	Discovery ID		✓		
12	Kundskabskanalen	✓	✓	✓	64	Animal Planet		✓		
13	TV4	✓	✓	✓	65	Nat Geo		✓		
14	NRK1	✓	✓	✓	66	Nat Geo Wild		✓		
15	NRK2	✓	✓	✓	67	History Channel		✓		
16	Das Erste	✓	✓	✓	68	H2		✓		
17	ZDF	✓	✓	✓	69	Cartoonito		✓		
18	NDR	✓	✓	✓	71	Disney Channel		✓		
19	RTL	✓	✓	✓	72	Nick Jr.		✓		
20	SAT1	✓	✓	✓	73	Cartoon Network		✓		
30	Kanal 4		✓	✓	74	Nickelodeon		✓		
31	Kanal 5		✓	✓	75	Sport Live		✓		
32	6'eren		✓	✓	76	Canal 9		✓		
33	TV3+		✓	✓	77	TV2 Sport		✓		
34	TV3		✓	✓	78	Eurosport 1		✓		
35	TV3 Puls		✓	✓	79	Eurosport 2		✓		
36	TV2 Charlie		✓	✓	80	TV3 Sport		✓		
37	TV2 Echo		✓	✓	81	TV3 MAX		✓		
38	TV2 News		✓	✓	82	Viasat Golf		✓		
39	TV2 Fri		✓	✓	83	TV2 Sport X		✓		
40	MTV 80's		✓	✓	84	Ultra HD kanalen		✓		
50	Viasat History			✓						
51	Viasat Explore			✓						

Synsfortolkning & regions kanaler

201	DR1 Syn
202	DR2 Syn
203	TV2 Syd
204	TV2 Fyn
205	TV2 Øst
206	TV2 Nord

Radiokanaler

Kanal	Frekvens
1000	DR P1
1001	DR P3
1002	DR P4 KBH
1003	DR P5
1004	DR P6 Beat
1005	DR P8 Jazz
1006	DR Klassisk
1007	Radio 4
1008	Pop FM
1009	Radio 100
1010	Nova FM

Radiokanaler direkte i tv'et eller via FM radiostik

Kanal	Frekvens
1011	Nova FM
1012	The Voice
1013	NDR 1
1014	NDR 2
1015	NDR Kultur
1016	Njoy
1017	MyRock
1018	Retro Radio
1019	Retro Radio Mil.
1020	Schleswig Hol.

Kanalsøgning:

DVB-C: (kabel-tv)

Udbyder: Vælg anden eller manuel

Søgetilstand: Hurtig

Frekvens: 143.000 (eller 143)

Søgetilstand: Hurtig

Qam: 64

Symbolrate: 6875